



BEAMZ
MADE
EAZY

155.130_155.132 V1.0

SFP100

QUICK START GUIDE

CONTROL MENU

MENU	VALUE	DESCRIPTION
A001	001-512	DMX control mode
L001	000-100	Brightness adjust
3200	3200-5600	Color temperature adjust
FH99	01-99	Strobe effect from slow to fast

NOTE: In A001 mode, the brightness and color temperature can be adjusted through the knob (it needs to be in the state of not triggering the console or buttons, and if triggered, it needs to wait for about 10 seconds to adjust).

DMX CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	GENERAL DIMMING	000 - 000	Off
		001 - 255	Dimming from dark to bright
2	COLOR TEMPERATURE ADJUST	000 - 255	Color temperature from 3200K to 5600K
3	STROBE EFFECT	000 - 000	Off
		001 - 255	Strobe from slow to fast



A series of horizontal dotted lines for writing, spanning the width of the page.





BEAMZ

**YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT**



is a leading developer of lighting products, including intelligent DMX moving heads, wireless battery operated DMX effects, static washes, sound-activated club effects, strobes & blacklights, LED lighting, fog and special effects machines, lasers and indoor and outdoor architectural lighting, as well as lighting controllers and protective bags.

