

Network Switch Gigabit + PoE

Algemene informatie

The Edimax GS-1008P V2 is an Eight PoE+ Port Gigabit switch designed for use in home, small or medium sized network environments. With eight DIP switches, PoE ports can be manually set with on/off control, extending PoE delivery distance up to 200 meters and port-based on/off control for VLAN and QoS is also supported. The switch easily connects and supplies power to PoE-enabled devices such as wireless access points, network cameras and IP phones as well as other Ethernet-enabled devices such as computers, printers or network attached storage (NAS). The compact size and fan-less design make the switch an ideal solution for expanding home and small business networks.

Eigenschappen

- Eight 10/100/1000Mbps Gigabit PoE+ ports
- IEEE 802.3af/at PoE compliant for simplified deployment and installation.
- Up to 30W per PoE port (total power budget: 130W) for powering PoE-enabled devices.
- Auto-detection of powered devices (PD) and power consumption levels.
- Hardware DIP switch for "Standard" and "Extend" mode selection; the "Extend" mode features 30-watt PoE transmit distance of 200m at speed of 10Mbps
- Port-based VLAN and Loop Protection features
- Supports 802.1p Quality of Service (QoS)

Specificaties

PoE Ports:	10
Type apparaat:	Switch
Aantal LAN-verbindingen:	8
Type stekker:	Euro
Kleur:	Zwart
Materiaal:	Plastic



Verkoopinformatie

Ordercode:	GS-1008P V2
Productomschrijving:	Netwerk Switch Gigabit + PoE
Verpakking:	Giftbox
Merknaam:	Edimax



Aantal	LxBxH (mm)	Gewicht
1	280x75x325	2423 gr.
8	355x315x620	20380 gr.

Netwerk Switch Gigabit + PoE

Ingang(en):	1x RJ45
Uitgang(en):	8x RJ45
Netwerktipe:	Gigabit
Aansluiting:	Bedraad
Aansluiting:	LAN
Type connector:	RJ45