## DConXi \*\*Datasheet DConXi

The DCon series features three advanced products, all designed to fit standard European in-wall junction boxes with a depth of 50mm and compatible with widely used EU cover frames, making them perfect for seamless integration into commercial, educational, and entertainment AV environments.

This two-channel XLR input panel converts analog audio to Dante, the industry-standard audio-over-IP protocol. Each input is equipped with an adjustable preamp that offers up to 42dB of amplification plus -100 to +27dB digital gain, along with switchable Phantom Power for handling microphones and other audio sources with precision. DConXi also provides an API for integration with third-party control systems, making it an ideal choice for customized installations.





Technical	<b>  specifications</b>	DConYi
rechnica	i specifications	DCOUVI

Electrical		
Frequency response	20Hz - 20kHz, ±0.5dB	
Sample rate	48kHz	
Bit depth	24	
Input sensitivity	+4dBu	
Input Impedance	20KΩ(Balanced), 10KΩ(Unbalanced)	
Dynamic Range	> 100dB	
Singal-to-noise Ratio	> 100dB	
THD+N	< 0.003%@4dBu, 1KHz	
Preamp	Analog gain 0-42dB + Digital -100 - +27dB; 48V. PP. per ch.	
Power supply	Power over Ethernet IEEE 802.3af, Class 0.	
Power consumption	2 Watt	
Operating temperature	-10 - +40°C	
Operating humidity	5 - 95%	
Connections	1x RJ45; 2x Neutrik XLR Female with retention spring	
Dante	Ultimo UXT Dante / AES67	
Mechanical		
Controls and indicators	UDP API	
Weight	0,25kg; 0.54lbs - 0,16kg; 0.35lbs without frame	
Dimensions	Frame: 90x90mm.; Fixing plate 71x71mm;	
	In-wall part: 46x46x46mm; Total depth: 54mm.	
Mounting	Junction box screws spaced 60mm. or 60x60mm. grid.	
	Front panel: 2x M3 screw	
Packaging		
Master carton	брсѕ.	
Dimensions	157x128x73mm; Master carton: 165x390x155mm.	
Weight	0,4kg; 0.9lbs; Master Carton: 2,5kg; 5,5lbs	
General		
Compliance	CE; RoHS; DIN 49 075	
Warranty	2 years limited warranty	
EAN Code	8718868408884	

## For latest product information, visit our website:

## www.newhank.com