

Datasheet T-Rack

NEW-HANK
QUALITY AV PRODUCTS



This 17.3" UHD touchscreen combines advanced technology with practical design to deliver reliable performance for professional applications. Whether used for control systems or video monitoring, it provides exceptional clarity and seamless integration.

With flexible mounting options, the display can be installed using the included 19" rack brackets for standard setups or the VESA100 mounting points for custom configurations. This adaptability ensures it fits easily into a variety of environments, making it a practical choice for diverse needs.

User-Friendly Features

A multifunction power button on the front panel enhances usability, allowing quick switching between inputs, powering the device on, or setting it to standby. The functionality of this button can be customized through the on-screen menu, providing users with a tailored experience that adapts to specific workflows.



Datasheet

T-Rack

Key features

- High-Resolution Display:
17.3" diagonal display with a stunning 3840 x 2160 UHD resolution, delivering a crystal-clear 255 PPI for superior image quality. Perfect for high-precision control and video Monitoring.
- Multi-Touch Functionality:
Projected Capacitive 10-point multi-touch technology allows intuitive operation, enabling precise control for applications requiring direct input.
- Versatile Input Options:
Equipped with two HDMI inputs and one DisplayPort input for maximum compatibility with modern devices. Easily connects to any system requiring touch or video input.
- Durable and Ergonomic Design:
 - Sturdy rack-mountable 19" chassis for seamless integration into studio setups or control systems.
 - Mountable via the included 19" rack brackets or VESA100 mounting points on the back for versatile installation.
- Dual Purpose:
 - Operates as a touch input device for systems accepting touch input over USB.
 - Serves as a high-quality UHD video monitor for professional monitoring purposes.

Technical specifications

Touch Technology	Projected Capacitive
Touch Points	Supports up to 10 simultaneous touch points
Display	17.3" LTPS TFT-LCD LCM
Aspect Ratio	16:9
Resolution	3840 (RGB) x 2160, UHD 255 PPI
Color Depth	1.07 billion colors, 98% DCI-P3 coverage
Luminance	500 cd/m ² (Typ.)
Viewing Angle	89°/89°/89°/89° (Typ.) (CR ≥ 10)
Power Supply	100-250V AC 50-60 Hz to 12V DC power supply included.
Power Consumption	Maximum 36 Watts; Standby < 0.3 Watts
Dimensions	440,5 x 266 x 38 mm; or 19", 7U, depth 38 mm when rack-mounted
Weight	4,1 kg
Packaging	
Dimensions	605x338x86mm.
Gross-weight	4,6kg; 10lbs
General	
Compliance	CE; RoHS
Warranty	2 years limited warranty
EAN Code	8718868408228

For latest product information, visit our website:

www.newhank.com